



832 FLEXINET VALVED P3 DUST MASK

EN 149 :2001+A 1 :2009 FFP3D

CODE RPFP3VB

UOM: BOX OF 5

Cup mask respirator with flexible cover & improved face seal. Grill protects against possible damage to the filter. Hand welded seal & modern design valve ensures lower breathing resistance

- Offers an assigned protection factor (APF) of 20 x Workplace Exposure Limit (WEL) for fine non-toxic dusts, fibres, fumes and mists
- The mask has extremely low breathing resistance due to the design and protective shield
- No metal parts it is ideal for use within the medical and pharmaceutical industry
 - One size fits all
- Limitations of use apply



LIMITATIONS OF USE

- Protection will only be offered if the mask is fitted correctly
- The mask, when in contact with the skin may cause allergic reactions to susceptible individuals. If this occurs leave the hazard area, remove mask and seek medical advice
 - The use by date is printed on the outer packaging
 - Do not use where exposure to chemical gases may be experienced
- Use in well ventilated areas only, which are not deficient in oxygen and do not contain explosive atmospheres
- Ensure good seal around the face is created before entering the hazard area
 - The working life of the mask is nominally one day (this is based on an working day shift of 8 hours), however it may be affected by many factors, including work rate, airflow and concentration of any contaminant in the atmosphere. The mask should be changed immediately if Breathing difficulties due to clogging are experienced, Breakthrough of a contaminant is detected by smell, taste or any other means, or The mask becomes damaged
- This mask is not designed to be worn by people with facial hair